PACKAGES CONVERTORS LIMITED BU-FC

Document type Work Instructions

Title

Work Instructions for setting of rotary embossing Unit

1. Purpose:

To ensure that the setting of rotary embossing die shall be carried out under controlled conditions.

Prepared by	Approved by	PAGE	REV	DATE	DOC NO.
Hassan	BUM FC	1(1)	4	01.07.2024	WILEMANIC/CL/4.9/02

Reviewed on (Date):	Reviewed on (Date):	Reviewed on (Date):	Reviewed on (Date):
Reviewed by:	Reviewed by:	Reviewed by:	Reviewed by:
Approved on (Date):	Approved on (Date):	Approved on (Date):	Approved on (Date):
Approved by:	Approved by:	Approved by:	Approved by:

2. Scope:


These instructions are applicable to setting of rotary embossing die.

3. Overall responsibility:


Overall responsibility lies with the production manager carton line.

4. Instructions:


Sr. #	Activity	Responsibility
4.1	Remove the protective paper from the embossing rollers	Operator




Sr.#	Activity	Responsibility
4.3	Turn selector S46G to position "1" to turn on the air supply	
of Tunna	printing units at 12'o clock.	
4.5	Push the embossing unit into the machine.	Operator



Sr. #	Activity	Responsibility
4.6	Free the wheel of the embossing unit by moving the screw.	Operator
4.7	Push further the embossing unit till it reaches to its position.	
4.8	Turn selector S46G to "0" position to stop the air pressure.	





Sr. #	Activity	Responsibility
4.11	Thread the web into the embossing unit.	Operator
4.12	The embossing rollers can be lifted or lower with the help of selector S20G the cutter- creaser panel.	Operator.
4.13	To remove the embossing unit, o the same in the reverse order. Use selector S40G on the embossing unit panel to push the unit out of the machine.	Operator

